

# RM SENSOR

The RM Sensor prevents your automatic sprinkler system from irrigating when it rains. The rain sensor can be adjusted to accommodate rainfall of 3 - 25 mm. The freeze sensor prevents pipe damage caused by freezing water. RM Sensor includes a control feature.



## FEATURES AND BENEFITS

- Can be adjusted to 3, 6, 12, 19 or 25 mm rainfall
- For use with all types of 24 VAC controllers
- 10 meters of connection wire included
- Model threads : 1/2" NPT or 1/2" slip



### Postadress:

TRÄDGÅRDSTEKNIK AB  
Helsingborgsvägen 578, Varalöv  
262 96 ÄNGELHOLM

Telefon : 0431-222 90  
Bg.nr : 5743-7980  
Org.nr : 556409-6120

### URL:

[www.tradgardsteknik.se](http://www.tradgardsteknik.se)  
E-postadress:  
[info@tradgardsteknik.se](mailto:info@tradgardsteknik.se)